

TN / Telenorma Herstellcode

Th. Göbel
20.03.2008

Jahr	Siemens-Code	BOSCH-Code	T&N-Code (1)	T&N-Code (2)	Bemerkung; Beispiele
1959	N		-A		8-A = August 1959
1960	P		-B		10-B = Oktober 1960
1961	R		-C		
1962	S		-D		
1963	T		-E		2-E = Februar 1963
1964	U		-F		
1965	V		-G		
1966	W		-H		
1967	X		-J		
1968	Y		-K		
1969	Z		-L		
1970	A		-M	A(-)	9-M = Sept. 1970; 10-A = Okt. 1970 (Code-Umstellung September/Oktober 1970)
1971	B			B	4B = April 1971, Kunststoff: 1971
1972	C			C	2C = April 1972 ?
1973	D			D	OD = Oktober 1973
1974	E			E	
1975	F			F	5F BP = Mai 1975 ?
1976	H			G	OG BP = Oktober 1976 ?
1977	J			J	6J BP; J7 BP (Formatumstellung: MJ nach JM; Juni/Juli 1977)
1978	K			K	K6 BP = Juni 1978 ?
1979	L			L	LO BP = Oktober 1979
1980	M			M	
1981	N			N	N2 BP = Februar 1981
1982	P			P	P5 BP = Mai 1982 ?
1983	R			R	
1984	S			S	
1985	T			T	TO BP = Oktober 1985
1986	U			U	U3 BP = März 1986
1987	V			V	VN BP = November 1987 ?
1988	W			W	LP: W1 BP = Januar 1988; 'Klartext: TK40-20 mit 88 01
1989	X				(Ab 1/1988: Herstelldatum im Klartext)
1990	A	A ?			
1991	B	B ?			
1992	C	C ?			
1993	D	D ?			
1994	E	E ?			
1995	F	F ?			
1996	H	H ?			
1997	J	J			BOSCH-Werk Limburg (EWSD-Fertigung)
1998	K	K			
1999	L	L			
2000	M	M			
2001	N	N			
2002	P	O			(Bei S&H: "P")
2003	R	R			
2004	S	S			
2005	T	T			
2006	U	U			
2007	V	V			

Monat	Kennung
Jan	1
Feb	2
Mrz	3
Apr	4
Mai	5
Jun	6
Jul	7
Aug	8
Sep	9
Okt	O
Nov	N
Dez	D